



Wood Cleaner, no perfume, 2.5 L

SKU: 1789

The wood cleaner is a basic cleaner for all types of wood and wood surfaces. The wood cleaner effectively removes grease, dirt and residue from old cleaning and care products. The wood cleaner is also free of solvents and for raw, sanded or planed wood, the wood cleaner improves the quality of the oiled surface and intensifies the color effect. .

- Does not contain perfume or pigments
- Applicable to all types of wood and wood surfaces
- · Solvent free

Specifications

Category	Floor wash, Floor care
BrandSymbol	WeClean'
Use on	
Allergy information	No Perfume
Form	Liquid
Volume (I/kg)	2.50
Dosage	5 ml per 1 L water
pH-Consentrate	13.5
Inner packaging	PE
Outer packaging	PE
Outer packaging - size	L33 x W30.5 x H30 cm
Ingredients	Phosphate
Sprayhead included	No
Gross weight (kg)	2.625
Net weight (kg)	2.5
Commodity Number	3402909000