

Product






Citric Acid, no perfume, 1 kg

SKU: 10385

Citric acid is used for the descaling of dishwashers and coffee machines. Powder product is dissolved in water before use and refilled. The acid is also suitable for descaling of washing machines and kettles.

- Do not use with chlorine-containing products
- Does not contain perfume

Specifications

Category	Limescale removal
BrandSymbol	WeClean® F31
Use on	 
Allergy information	No Perfume
Form	Powder
Volume (l/kg)	1.00
Dosage	5 g per 1 L water
pH-Consentrate	1.5
Inner packaging	PE
Outer packaging	Carton
Outer packaging - size	L15 x W15 x H13 cm
Sprayhead included	No
Sprog på etiket	DK
Danger!	
Gross weight (kg)	1.1
Net weight (kg)	1
Commodity Number	3402909000